

D-301BLK, D-302BLK

TYPE: Drain Trim and Overflow Cover for Bathtubs

FINISH: Matte Black

STANDARD INSTALLATION

1. Separate all mounting hardware.
2. Apply plumbers putty or silicone to the underside of drain body flange.
3. Place drain body #3 into tub drain opening.
4. Place rubber seal #2 onto the top of the threaded drain flush with the tub.
5. Carefully thread drain #1 into drain pipe. DO NOT OVER TIGHTEN.
6. Protect with spray wax protectant (W900-WAX).

Note: There is no mounting nut included. A 1.5" ABS locking nut or similar (found at a hardware store) may be necessary to complete installation.

FOR OVERFLOW BATHTUBS

1. After installing the bathtub drain, place the overflow cap #4 in front of the brace #5. Next, thread the screw #6 through overflow cap and brace and then into the overflow pipe.

FOR NON-OVERFLOW BATHTUBS

1. After installing the bathtub drain, you may discard pieces #4, #5, and #6, as they are not needed for this assembly.

CARE & CLEANING INSTRUCTIONS

- Do not use alkaline, acid based detergents, abrasive polishes, scouring cleansers, S.O.S. Pads or scotch brite pads when cleaning your decorative lavatory drains.
- Do not leave corrosive chemicals or solids laying in the bottom of the sink basin, such as coffee grounds, vinegar, etc.
- After normal use, always wipe the exposed surface area of your drain with a clean soft cloth. This will aid in limiting water spots.
- For normal cleaning, just wipe with a damp cloth and dry with a soft cloth.
- If a chemical cleaner is required when cleaning, windex or a mild dish washing soap can be used.

MORE INFORMATION



YOUTUBE



WEBSITE

INFO@PREMIERCOPPERPRODUCTS.COM | PREMIERCOPPERPRODUCTS.COM
425 E. PINNACLE PEAK RD. STE 170, PHOENIX, AZ 85024 | (602) 476-7332

SUGGESTED ACCESSORIES

W900-WAX

Spray Wax Protectant

