

DK87

Bluetooth Pairing: Turn the toggle (at the back of your keyboard) to “BT”, long press FN+Q/W/E (connected up to 3 devices) for 3 seconds to enter into pairing mode.

Bluetooth Device Name: A87-BT5.0KB / A87-BT3.0KB

Wireless Pairing: Turn the toggle (at the back of your keyboard) to “2.4G”, long press FN+R for 3 seconds to enter into pairing mode.

Wired Mode: Turn the toggle (at the back of your keyboard) to “TPC”, connect your keyboard to the computer using wire.

FN+Q=Bluetooth Device 1

FN+F1=This PC

FN+W=Bluetooth Device 2

FN+F2=Desktop

FN+E=Bluetooth Device 3

FN+F3=Email

FN+R=Wireless Mode

FN+F4=Calculator

FN+INS=Swap RGB Mode

FN+F5=Player

FN+DEL=Swap RGB Colour

FN+F6=Stop

FN+A=Swap to Windows Mode

FN+F7=Previous Song

FN+S=Swap to MAC Mode

FN+F8=Pause/Play

FN+↑=RGB Brightness+

FN+F9=Next Song

FN+↓=RGB Brightness-

FN+F10=Mute

FN+←=RGB Speed-

FN+F11=Volume-

FN+→=RGB Speed+

FN+F12=Volume+

FN+WIN=Lock Windows Key

FN+ESC=Reset to Factory Settings (Long Press for 3 Seconds)

Keyboard Charging Indicator

Red FN Key: Low Battery

Green FN Key: Charging