

TRESTON

Treston Ergo
Treston Ergo ESD

Ident. - Nr. 53806.0000.01



C20PU
C30AL
C30BL
C30B

C25PU
C35AL
C35BL
C35B

C20PU-ESD
C30AL-ESD
C30BL-ESD
C30B-ESD

C25PU-ESD
C35AL-ESD
C35BL-ESD
C35B-ESD

Assembly and operating instructions
Montage- und Bedienungsanleitung
Instructions de montage et mode d'emploi
Asennus- ja käyttöohjeet
Monterings- och bruksanvisning
Инструкция по сборке и эксплуатации

Treston Oy
Sorakatu 1, 20730 Turku Finland
Tel. +358 10 4469 11 · Fax +358 10 4469 789
sales@treston.com · www.treston.com

A

page 4 - 9



E

page 16 - 17



B

page 10 - 11



F

page 18 - 19




C

page 12 - 13



G

page 20




D

page 14 - 15




H


page 21




A




3




4





5




6




B






C









D



E



F



G



H



www.bimos.de/cleaning.html



