

Trilogy-990 Quick Reference Guide



Antenna / Rubber duck antenna, is a sma jack (pin) the radio is a female sma socket hole.

Channel selection, Select your talk group or simplex channel

Power / volume, use to switch on and off, keep turning clockwise to increase the volume

Analogue / Digital, press for 7 seconds to swap between modes

Menu up and down, use this key to move between talk groups or simplex channels

Menu access, All other features can be accessed from here

Power level, press and hold for 7 seconds to swap between high 5W and low 1W

PTT / transmit, the all-important talk button, please key for 1-3 seconds before talking

Zone / Repeater change, press and hold for 7 seconds to change between repeaters