




MANHATTAN COMFORT

DK2081






STOP!


Before beginning the assembly process, ensure all boxes and parts have been delivered.

FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



TOOLS REQUIRED



View our assembly video online:
WWW.MANHATTANCOMFORT.COM




Stuck? Question? We are here to help.
tel: 908-888-0818
e-mail: help@manhattancomfort.com

Support Site




Included in this package:

- A. Top Panel (1)
- B. Left Side Panel (1)
- C. Right Side Panel (1)
- D. Middle Left Side Panel (1)
- E. Middle Right Side Panel (1)
- F. Left Front Panel (1)
- G. Right Front Panel (1)
- H. Back Panel (1)
- J. Drawer Front Panel (1)
- K. Drawer Left Side Panel (1)
- L. Drawer Right Side Panel (1)
- M. Drawer Back Panel (1)
- O. Drawer Bottom Panel (1)
- P. Connecting Tube (1)




Hardware Identification


① CAM SCREW - 38PCS




② HIDDEN CAM - 38PCS




③ APPLIQUE CARD - 7PCS



④ WOOD DOWEL - 13PCS



⑤ PULL - 1PC




⑥ PAN HEAD SCREW
M5*50mm - 2PCS



⑦ PAN HEAD SCREW
M5*35mm - 8PCS




⑧ HEX HEAD SCREW
M6*12MM - 4pcs







⑨ FLAT HEAD SCREW
M4*12mm - 2pcs






Step 1

- ◆ Lock 38 Cam Screw (1) onto the Top Panel (A), the Left and Right Side Panel (B, C), the Left and Right Front Panel (F, G), and the Drawer Front Panel (J).




Step 2

- ◆ Lock 14 Hidden Cam (2) into the Left and Right Side Panel (B, C), and the Left and Right Front Panel (F, G).



Step 3




- ◆ Lock 24 Hidden Cam (2) into the Middle Left and Right Side Panel (D, E), and the Drawer Left and Right Side Panel (K, L).



Step 4





- ◆ Use the Pan Head Screw (7) and the Wood Dowel (4) to fix the Back Panel (H) onto the Middle Left and Right Side Panel (D, E). Pay attention to the orientation.

Pay attention to the orientation.







Step 5

- ◆ Use the cam locks to fix the Left and Right Front Panel onto the Middle Left and Right Side Panel (D, E).






Step 6

- ◆ Use the cam locks to fix the Left and Right Side Panel onto the Left and Right Front Panel (F, G).








Step 7

- ◆ Use Pan Head Screw (6) and Hex Head Screw (8) to fix the Connecting Tube (P) onto the Left and Right Side Panel (B, C) and the Middle Left and Right Side Panel (D, E).





Step 8

- ◆ Attach the Left and Right Side Panel (B, C) and the Back Panel (H) to the Top Panel (A). Secure the components using the Wood Dowel (4) and cam lock connectors.




Step 9

- ◆ Use the Pan Head Screw (7) to fix the Drawer Left and Right Side Panel (K, L) onto the Drawer Back Panel (M).







- ◆ Slide the Drawer Bottom Panel (O) into the grooves of the Drawer Side Panel (K, L) and the Drawer Back Panel (M).






Step 10

- ◆ Use the cam locks to fix the Drawer Front (J) onto the Drawer Side Panel (K, L).




Step 11

- ◆ Use the Flat Head Screw (9) to fix the Pull (5) onto the Drawer Front (J).




Step 12

- ◆ Align the slides and push the drawer into the unit.



Step 13

- ◆ Peel APPLIQUES from the APPLIQUE CARD (3) and stick them onto each visible HIDDEN CAM.





MANHATTAN COMFORT

WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.



319 Ridge Rd. Dayton, NJ 08810

908-888-0818