


EURONICS


User Manual & Instruction

EAS Stainless Steel Air Curtain



INSTALLATION:

1. **Unscrew the mounting plate and take it off. (Fig.1、 Fig.2)**
2. **Drill a hole as the instruction. Then put into the blot and fix it with cement.**
3. **Hanging on the mouchine plate and ensure fix it.**
4. **Installing the machine onto the mounting plate and ensure the safety, than fix it tighten with screws.**



(Fig. 1)




(Fig. 2)

CAUTIONS / INSTALLATIONS:

During installing the unit, please pay special attention to the following points in order to obtain the ultimate efficiency.

1. **Install on solid place to avoid vibrations when machine is running and also for safety reason unnecessary noise caused by vibration can be prevented.**
2. **AIR CURTAINS are used for indoor purpose.**
3. **Depending on the height to choose the most suitable model. If it fixed too high, the shut-off distance will be affected then the efficiency will be reduced.**
4. **The air is drawn in front of the unit and is blown out downwards.**
5. **Several units can be mounted next to each other when wide door opening occur. Under such condition, a narrow space in between 20-40mm may happened.**
6. **During installation, the mounting plate should not have a gap between the walls.**
7. **The distance between the unit and the ceiling must reserve at least 30mm.**
8. **The unit is installed horizontally.**
9. **Recommend installing the machine at the height of at least 2.3M above the ground.**
10. **A triple pole switch should precede the appliance with at least 3mm breaking gap.**




Model No	Power (W)		Air Velocity (m/s)		Air Flow (m3/h)	Noise (dB)		Dimension (mm)
	HI	LO	HI	LO		HI	LO	
EAC3/EAS3(900mm)	410	320	21.0	17.5	1520	52	49	900x230x212
EAC4/EAS4(1200mm)	560	450			2027	54	51	1200x230x212
EAC5/EAS5(1500mm)	700	560			2543	55	53	1500x230x212
EAC6/EAS6(1800mm)	820	670			3040	58	56	1800x230x212

EURONICS

Super Slim Air Curtain

Please read instructions before commencing Installation and retain for future reference

DIAGRAM:



PRODUCT OUTLINE:

AIR CURTAINS are designed for installation in shops, office buildings, hotels and restaurants doorway. They discharge a curtain of air, which effectively shut out outside air. Use them to keep out insects, unpleasant smells, and dust from indoor where a large number of people pass in and out. These air curtains also prevent air escaping from an air-conditioned room.

CONDITIONS OF USE:

Please **DO NOT** install the unit under following conditions:

1. Do not operate ambient temperature over 50° c or below -10° c.
2. A relative humidity over 95% at room temperature and steamy area.
3. Contains of oily smoke.
4. Materials or gases may cause explosion.
5. Nearly corrosive gases.
6. Locate in where may be sprinkle with water.