

Fuses and relay Mercedes-Benz Actros mp3 / mp2

26.07.2022

Content

- [Fuse and relay box](#)
 - [Circuit breakers](#)
 - [Relay](#)

Mercedes-Benz Actros mp3 preset 3 generations of the Mercedes Actros lineup, Mercedes Actros mp2 - 2 consumables Years of manufacture Mp2: 2003, 2004, 2005, 2006, 2007. Mp3: 2008, 2009, 2010, 2011, 2012. The most popular Mercedes-Benz Actros 1844 1841. In this article you will find a description of the fuses and relays Mercedes Actros mp3 mp2 with a block diagram and its location, the presence of a cigarette lighter fuse.

Not schemes or not that generation?

Fuse and relay box

The main fuse and relay box is located in the cabin, in the passenger's footwell. To access it is necessary to remove the protective cover, with fasteners on the sides.





Photo example




Please note that there is no one general description for all Mercedes Actros mp2 and mp3 models. The assignment of the elements of the execution of the lateral side can be different. Check the actual Georgia with your diagrams on the block cover.

Example of a circuit with a block cover



F1-20A
F2-20A
F3-20A
F4-20A
KI.30
F5-15A
derm
F6-25A
anla
F7-25
nun
F8-20
12V
ada
F9-10
F10-1
ass
F11-
Flo
To
F12-
wi
st

scheme



transcript

Circuit breakers

- F1 20a driver's door (modern ESSES
- F2 20A reserve
- F3 20A passenger door (door control module)
- Cancellation of modernization F4 15A
- F5 20A Screw socket 15-pin
- Panel overlay module F6 10A MSF
- F7 30a retarder control, parameter stood, s, alarm siren, refrigerator, tieti, tieti)
- F8 30A front passenger seat with damper suspension, parking air conditioner, rotating beacon,
- F9 30A Female clamp 7-pin
- F10 30A tomato with p
- F11 15A brake control module
- Cancel upgrade F12 30A
- Audio amplifier F13 20A, telematics
- F14 10A FR control module, ignition switch
- F15 20A heater control panel
- F16 10A lamp for light, ceiling lamp for light
- F17 10A instrument panel, tachograph, diagnostic socket
- F18 20A sunroof

- F19 30A Brake control
- Cancel upgrade F20 10A
- F21 10A engine management system, alternator
- F22 10A Clip for socket 7-pin
- F23 15A Female terminal 15-pin, – Female terminal 7-pin
- F24 15A Battery heating, Racor filter heating, solenoid valve - dual chamber water separators
- F25 10A diagnostic problem
- F26 30A electric torch air heater, driver's seat with dampened suspension, parking air conditioner, lane keeping assistant, electronic-hydraulic additional drive, sun visor motor, engine compartment light, cargo platform light
- F27 20A heater panel upgrade, telematics
- F28 10A traffic system upgrade
- F29 10A Brake control
- F30 10A SRS seat belts, airbags, instrument panel
- F31 10A audio system, 24 volt cigarette lighter sensor
- F32 10A cigarette lighter 12 volt

Relay

- K1 - trailer socket
- K2 - Heating
- K3 - Engine Control / Generator
- K4 - Reserve
- K5 - Cigarette lighter relay

Individual fuses and relays play a role outside of this unit.