




Model: AF006









STOP!


Before beginning the assembly process,
ensure all boxes and parts have been delivered.

FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



TOOLS REQUIRED



View our assembly video online:
WWW.MANHATTANCOMFORT.COM




Stuck? Question? We are here to help.
tel: 908-888-0818
e-mail: help@manhattancomfort.com







Support Site



Metal Accent Cabinet



Hardware list

A	B	C	D	E	F	G
						
M5×12mm 10 ×	M4×4mm 4 ×	96mm 2 ×	4 ×	8 ×	2 ×	2 ×
H	J	K	L	M		
						
M4×40mm 2 ×	Ø8×40mm 2 ×	6 ×	4 ×	4 ×		

① Left Side

1×

② Right Side

1×

③ Left Back

1×

④ Right Back

1×

⑤ Top

1×

⑥ Shelf

1×

⑦ Bottom

1×

⑧ Left Door

1×


⑨ Right Door

1×


⑩ Leg

2×

STEP 1




Fit the height-adjustable feet L on the bottom of Leg ⑩



”


STEP 2

- 1- Fit the Left side ① and Right side ② into Leg ⑩
- 2- Put the Part M into the Leg ⑩ to fix Left side ① and Right side ② together with Leg ⑩




STEP 3

Put Left back ③ and Right back ④ at the back





- 1- Fix Left back ③ and Right back ④ with Left side ① and Right side ② by Screws A
- 2- Fix Left back ③ and Right side ④ together by Screw A
- 3- Bend the small metal part on Left back ③ and Right back ④ to fix with Left side ① and Right side ②




STEP 4


Put Part K on the Screw A at the back side



STEP 5





- 1- Put Top ⑤ on the top
- 2- Fix Top ⑤ with Left back ③ and Right back ④ together by Screw A
- 3- Put Part K on the Screw A at the inner top side







STEP 6

- 1- Bend the small metal part on Left side ① and Right side ② to fix with Top ⑤
- 2- Fit Bottom ⑦ in diagonal position to insert it at the bottom of cupboard
- 3- Bend the small metal part on Left side ① and Right side ② to fix with Bottom ⑦









STEP 7

- 1- Fix Shelf clip E on the Left side ① and Right side ② and make sure in the same height
- 2- Fit Shelf ⑥ in diagonal position to insert it inside the cupboard
- 3- Place Shelf ⑥ on Shelf clip E







STEP 8

- 1- Fix Magnet D on the Left door ⑧
- 2- Fix Handle C on the door by Screw B




STEP 9

- 1- Fix Magnet D on the Right door ⑨
- 2- Fix Handle C on the door by Screw B








STEP 10

- 1 - To assembly the doors, fit lower hinge bolt of Left Door ⑧ into the hole on Leg ⑩ and make Gasket G between Leg ⑩ and lower hinge bolt of Left door ⑧
- 2 - Pull the upper hinge bolt of Left door ⑧ down, align the door and release the upper hinge bolt to fit the hole of Top ⑤
- 3- Repeat the step for Right Door ⑨





WARNING








“
1. Pay attention to the assembly of doors in order;
2. Part G is on the Part F
”



STEP 11



- 1- Mark the wall holes by a pencil
- 2- Drill the wall where marked on the wall
- 3- Insert Part H (plastic expansion bolt) into the holes
- 4- Use the hammer to insert part H until it overcomes the wall
- 5- Fix Part J at the Left back ③ and Right back ④ with wall





WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.


THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.




319 Ridge Rd. Dayton, NJ 08810
908-888-0818

Model: AF007



Metal Accent Cabinet




WARNING

Maximum weight supported by shelves

Hardware list


A	B	C	D	E	F	G
M5×12mm 25 ×	M4×4mm 2 ×	96mm 1 ×	4 ×	16 ×	1 ×	1 ×
H	J	K	L			
M4×40mm 2 ×	Ø8×40mm 2 ×	4 ×	4 ×			

① Left Side




1×

② Right Side




1×

③ Back




1×

④ Front Leg




1×

⑤ Back Leg




1×

⑥ Top




1×

⑦ Bottom




1×

⑧ Shelf




4×

⑨ Door




1×

STEP 1





Fix the height-adjustable feet L on the bottom of Front Leg ④ and Back Leg ⑤



STEP 2




Fix Triangular plate D on Front Leg ④ and Back Leg ⑤ by Screw A




STEP 3

1- Fix Left side①and Right Side②into Front Leg④and Back Leg⑤
2- Fix Triangular plate D with Left Side ① & Right Side ② and Front Leg ④ & Back Leg⑤






STEP 4

Fix Back③at the back with Left Side①and Right Side② by Screw A




STEP 5

1- Put Top ⑥ at the top
2- Fix Top ⑥ with Left Side ①, Right Side ② and Back ③ by Screw A





STEP 6



1- Put Part K on the
Screw A at the inner top side

2- Fix Bottom ⑦ in diagonal
position to insert it inside the
cupboard




STEP 7






1- Fix Shelf clip E on the Left Side① and Right Side② and make sure in the same height

2- Fit Shelf⑧ in diagonal position to insert it inside the cupboard






3- Place Shelf ⑧ on Shelf clip E




STEP 8


Fix Handle C on the door by Screw B





STEP 9



III




IV




1- To assembly the door,
fix Lower hinge bolt F of Door
⑨ into the hole on Front Leg④
and make Gasket G between
Door⑨ and Lower hinge bolt F

2 - Pull the upper hinge bolt of
Door⑨ down, align the door
and release the upper hinge
bolt to fit the hole of Top⑥



I










II



STEP 10



- 1- Mark the wall holes by a pencil
- 2- Drill the wall where marked on the wall
- 3- Insert Part J (plastic expansion bolt) into the holes
- 4- Use the hammer to insert part J until it overcomes the wall
- 5- Fix Screw H at the back ③ with the wall





WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.



319 Ridge Rd. Dayton, NJ 08810
908-888-0818