

---

## 3750 3/4 DRUMPATCH

### MAIN PATTERN

Prep: Reset, program

Main pattern data: AB, R, T, R, CO, R, AB, R, S, R, R, R,  
AB, R, T, R, CO, R, AB, WB, CO, R, S, S,  
AB, R, T, R, CO, R, AB, R, B, R, S, R,  
AB, R, T, R, CO, R, AB, CL, R, R, S, S,  
Repeat, Reset.

### BRIDGE PATTERN

Prep: Reset/Bridge, Program

Bridge pattern data: AB, R, CO, R, T, R, AB, R, R, R, S, CL,  
AB, R, B, R, CO, R, AB, CO, S, R, S, T,  
AB, R, CL, T, CO, R, AB, R, S, CO, S, R,  
R, AB, CO, CO, CO, CL, AB, CL, S, T, CO, CO,  
Repeat, Reset -----Play!

EACH PATTERN UTILIZES 48 EVENTS.

## COMMENTS

ALL DRUM PATCHES BY: CRAIG ANDERTON

The drum abbreviations are as follows:

AB - Accent Bass	CO - Conga
B - Bass	CL - Clave
S - Snare	WB- Wood Block
T - Tom Tom	R - Rest

Other programming steps are self-explanatory.

# 3750 5/4 DRUMPATCH

## MAIN PATTERN ONLY

Prep: Reset, program

Main pattern data: AB, S, R, R, S, R, AB, R, CO, R,  
AB, CL, R, R, CL, R, AB, R, S, S,  
AB, S, R, R, S, R, B, R, CL, R,  
AB, CO, R, WB, T, CO, R, AB, R, S, S,  
Repeat, Reset ----Play.

TAKES UP 40 EVENTS This is a 3 + 2 style of 5/4

## 3750 MAIN ROCK PATTERNS (bridges not included - use as melody patterns)

### MAIN PATTERN 1

Prep.: Reset, program

Main #1 data: AB, R, R, R, S, R, R, R, AB, R, B, R, S, R, R, R,  
AB, R, R, R, S, R, R, R, R, R, AB, R, S, R, S, S,  
AB, R, R, R, S, R, R, R, AB, R, B, R, S, R, R, R,  
AB, R, R, R, S, R, R, R, R, AB, R, S, S, CO, CO.

Main #2 data: AB, R, R, R, S, R, R, R, AB, R, AB, R, S, R, R, R,  
R, R, AB, R, S, R, S, R, R, R, AB, R, S, R, S, S,  
AB, R, AB, R, S, R, CO, AB, R, AB, R, S, R, T, T,  
T, T, T, R, CO, CO, CO, R, T, CO, AB, R, CL, T, CO, T.

Main #3 data: AB, R, R, R, S, R, R, R, AB, R, R, R, S, R, R, R,  
AB, R, AB, R, S, R, R, R, R, R, AB, R, R, R, S, R,  
AB, R, R, R, S, R, R, R, AB, R, R, R, S, R, CO, CO,  
AB, R, AB, R, S, R, R, R, R, AB, R, R, R, S, S,

Main #4 data: AB, R, R, R, S, R, R, R, AB, R, R, R, S, R, R, R,  
AB, R, AB, R, S, R, CO, T, AB, R, R, R, S, R, S, S,  
AB, R, CO, CO, S, R, T, T, AB, R, T, T, S, CO, T, R,  
T, T, T, T, CO, CO, CO, CO, S, S, S, S, CO, S, WB. S.

Each pattern requires 64 events.

Hit "Reset, Play" to play each program. No repeat required, due to use of the entire 64 event memory.

"Bridge" and "Score" switches may be changed during playback to move from one pattern to another.

# 3750 7/4 DRUMPATCH

## MAIN PATTERN ONLY

Prep: Reset, program

Main pattern data: AB, R, S, R, B, R, S, R, AB, R, S, R, R,  
AB, R, S, CO, B, R, S, CO, AB, R, S, S, R,  
AB, R, S, R, AB, R, S, R, AB, R, CL, CO, R,  
AB, R, S, CO, AB, R, S, CO, AB, R, S, S, R,  
Repeat, Reset, Play.

Takes up 56 events

THIS IS A 4 + 3 STYLE OF 7/4.

— **FOR YOUR OWN** —