

SOLAR GARDEN LIGHT

Instruction Guide (Orange tab model) E98 series

PLEASE READ THE FOLLOWING PRIOR TO INSTALLATION

IMPORTANT: This product contains a rechargeable Ni-CD/MH battery. Once the battery life is exhausted the battery must be disposed or recycled properly according to your local laws. Please contact your local disposal or refuse collection agency for more information.

1. Twist & remove the lens from the solar panel/roof of the light. Discard the ORANGE tab (slide the on/off switch if equipped) and the light will be "ON" (**the newer stainless steel model has a color switch for color changing operation option**). Turn the body lens counterclockwise until its 4 tabs engage with the ones on the cap. Attach the tube & ground stake. Push the stake into the ground, **water to soften the soil if necessary to avoid stake breakage**.
2. Install the light in direct sunlight for at least one (1) day. This is important so that its batteries are fully charged for a full night of lighting. The light has a daytime light sensor so once it is set to the "ON" position, it will function automatically. It is recommended that the battery should be replaced every one (1) or two (2) years or when the ON time is reduced significantly at night. **Please note that your solar light will not charge the battery in the "OFF" position. The more, sun shines, the longer the light lasts.**
3. Select an area to install your solar lights that is free of any obstructions that may cause shading to the solar panels. Please note that your solar light has a photocell light sensor and will not turn on if there is light, **please be sure to install your solar light where there are no street lights or porch lights that may prevent your light from turning on at night. The darker the area is, the brighter the light becomes.**
4. Please allow 10-12 charge & discharge cycles to maximize battery life.
5. Battery replacement: twist & separate the top, remove 3 screws (or twist to remove), replace the 1.2v x600mah (or higher) rechargeable battery (try not to break any tiny wires), with the top upside down on the floor (in a dark room to deactivate sensitive built-in daylight sensor) the led bulbs should light up, if not the unit is defective.
6. **Trouble shooting:**
 - * No light after full charge ---- jiggle the battery to make sure it contacts to its end fully or replace with a working battery to test it
 - * Unit last a couple hours at night: swap to a place with more sun light, let it charged and discharged a couple days if condition is still the same, new battery is needed**NOTE: Most of solar lights must have a 6 to 8 hours of full sun in order to charge its internal rechargeable battery. On cloudy days, it only receives the charging at minimum stage & won't last very long at night so how long the unit lights up at night depends on the weather locations, conditions & sunlight availability.**